

Fender Assembly Directions

Firmstrong



Most Firmstrong models allow you to add fenders. The fenders are attached via three chrome support brackets. One (1) for the front wheel and two (2) for the rear. Begin by attaching the front fender to the bolt on the back side of the fork (fig. 1). The support bracket attach to the fork (fig. 2) and to the fender itself using the supplied screws (fig. 3 & 4).



The rear fender is attached to the bike using the two (2) remaining brackets. Secure the brackets to the fender (fig. 5) then to the rear frame (fig. 6). It is best to tighten all the bolts after you secure the bottom fender bolt (fig. 7) to the frame to allow for adjustment, as this screw is in a tight spot between the fender and the tire (fig. 8). Now you can tighten down all the screws.